UBCO_Battery_Pinout



Pin position	Function
1	Charge positive
2	DC-DC positive
3	BMS switch in
4	BMS switch out
5	DC-DC negative
6	Charge negative

