

## 2017 2x2 6-month Service check

| Date:   |   |
|---------|---|
| Chassis | s/VIN Code:   |
|         | ner Name:   |
|         |   |
| Dealers | sillp.  |
|         |   |
|         |   |
|         |   |
|         | Clean bike and check all visible parts for signs of wear                                    |
|         | Check cable routing as per user manual  |
|         | Check kick stand operation and lubricate if necessary                                       |
|         | Check foot pedal mounts are tight and lubricate pivot                                       |
|         | Check swing arm bolt is tight   |
|         | Check horn and light operation  |
|         | Ensure Battery plug terminals are clean   |
|         | Battery plug retaining clip is installed  |
|         | Check headset is assembled correctly and there is no movement between fork and frame        |
|         | headtube. Adjust if necessary.  |
|         | Check all bike bearings for smooth operation, re-grease or replace if necessary.            |
|         | Check headset stem torque (15Nm)  |
|         | Check Wheel torque (80Nm)   |
|         | Check Brake mount screws (12 Nm)  |
|         | Check Motor cover screws (5 Nm)   |
|         | General cable wear. Inspect cables at entry and exit of front and rear consoles for correct |
|         | installation  |
|         | Check motor plug contacts (front and rear), pack with Vaseline if needed.                   |
|         | Set tire pressures (see user manual)  |
|         | Ensure equal spoke tension  |
|         | Lubricate throttle and ensure it moves smoothly and returns to the off position.            |
|         | Check hand grip condition, replace if necessary.  |
|         | Brake calipers are aligned with zero fluid leaks  |
|         | Check brake pad wear and advise customer if high performance pads are necessary.            |
|         | Check disc brake security and wear. Replace if necessary                                    |
|         | Ensure brake system is working correctly  |
|         | Check suspension for smooth operation. Commercial users may require their shocks to be      |
|         | cleaned and lubricated.   |
|         | Check hubs for excessive noise  |
|         | Commercial users will require their motors to be inspected for planetary gear wear /        |
|         | Bearing condition and general cleanliness.  |
|         | Remove battery and inspect battery case, check for any signs of damage on or under the      |
|         | battery.  |
|         | Check any carry out any updates due as required   |
|         | Test ride bike. Check all systems are working correctly and the bike runs as expected       |
|         |   |

| Technician Signature: |
|-----------------------|
|                       |
|                       |
|                       |